



## Lesson Plan – Painting on Glass

Celia Buchanan, National Marabu Artist Educator


Supplies:

Marabu Porcelain paints  
Glass plate, brush


Marabu Porcelain & Glas Painters (markers)  
(available in Fine or Universal tips)



Clean and dry the glass plate. Turn in over and place an image underneath for tracing if desired. Draw and color your image on the back of the plate with markers.



Once the image areas are dry, try scratching lines into the paint for added texture and interest.



Paint over the design with 2-3 coats of white Porcelain paint. The markers are semi-transparent, so colors other than white will affect the colors in your design.



Once the paint has fully dried, which may take several hours depending on the number of coats, gently scrape away any stray bits of paint in unwanted areas.

To cure, place the plate in a cold oven and preheat to 320°. Once 320° is reached, bake the plate for 30 minutes. Turn off the oven and allow to cool before removing. Your plate is now dishwasher-safe.

Porcelain paints used alone can also be air-cured in 72 hours (instead of baking) to be dishwasher-safe. Markers require curing in the oven to be permanent.